

FANUC FLEXIBOWL PLUGIN



**This Plugin was born with the idea of communicating quickly and safely with Flexibowl through FANUC robots.
The Plugin requires the "Fanuc User Socket Messaging" license for correct operation.**

FlexiBowl®



STEP 1:

CONFIGURING THE SOCKET MESSAGING OPTION

Overview

In order to use Socket Messaging, you need to configure the following network hardware and software parameters:

- On the client,
 - The IP address or name of your server
 - The port on the server that you want to use for socket messaging.

Setting up a Client Tag

You need configure the client tags you want to use for socket messaging.

Note If the client tags you want to use are being used by a network protocol other than TCP/IP, you need to undefine the tags before they can be used for socket messaging.

Procedure To Setting up a ClientTag

Conditions

- The tag you want to set up is not configured to be used by another device on your network.

Steps

1. Cold start the controller.
 - a. **On the teach pendant**, press and hold the SHIFT and RESET keys. Or, **on the operator panel**, press and hold RESET.
 - b. While still pressing SHIFT and RESET on the teach pendant (or RESET on the operator panel), turn on the power disconnect circuit breaker.
 - c. Release all of the keys.
2. On the teach pendant, press MENUS.
3. Select SETUP.
4. Press F1, [TYPE].
5. Select Host Comm.
6. Press F4, [SHOW].
7. Choose Clients.
8. Move the cursor to the tag you want set up for Socket Messaging, and press F3, DETAIL.

You will see screen similar to the following.

```
SETUP Tags

Tag C3:

Comment:          *****
Protocol Name:    *****
Current State:    UNDEFINED
Startup State:
Server IP/Hostname:*****
Remote Path/Share:*****
Port:             *****
Inactivity Timeout: 15 min
Username:         anonymous
Password         *****
```

9. Move the cursor to the Protocol Name item, and press F4, [CHOICE].
10. Select SM.
11. Move the cursor to the Startup State item, press F4, [CHOICE], and choose DEFINE.
12. Move the cursor to the Server IP/Hostname item, and press ENTER.
13. Type in hostname or IP address the of the remote host server you want to use for socket messaging.
- Note** If you are not using DNS, you must add the remote host and its IP address into the host entry table.
14. Press F2, [ACTION], and select DEFINE.
15. **Set the system variable:**
 - a. Press MENUS.
 - b. Select NEXT.
 - c. Select SYSTEM, and press F1, [TYPE].
 - d. Select Variables.
 - e. Move the cursor to \$HOSTC_CFG, and press ENTER.
 - f. Move the cursor to the structure corresponding to the tag selected in [Step 8](#) . For example, if you are setting up tag C3, move the cursor structure element [3], as shown in the following screen.

```

SYSTEM Variables
$HOSTC_CFG
 1  [1]          HOST_CFG_T
 2  [2]          HOST_CFG_T
 3  [3]          HOST_CFG_T
 4  [4]          HOST_CFG_T
 5  [5]          HOST_CFG_T
 6  [6]          HOST_CFG_T
 7  [7]          HOST_CFG_T
 8  [8]          HOST_CFG_T
    
```

- g. Press ENTER. You will see a screen similar to the following.

```



SYSTEM Variables
$HOSTC_CFG[3]
 1  $COMMENT      *uninit*
 2  $PROTOCOL     'SM'
 3  $PORT         *uninit*
 4  $OPER         3
 5  $STATE        3
 6  $MODE         *uninit*
 7  $REMOTE       *uninit*
 8  $REPERRS      FALSE
 9  $TIMEOUT      15
10  $PATH         *uninit*
11  $STRT_PATH    *uninit*
12  $STRT_REMOTE  *uninit*
13  $USERNAME     *uninit*
14  $PWRD_TIMEOUT 0
15  $SERVER_PORT 0
    
```




- h. Move the cursor to \$SERVER_PORT. Type in the name of the TCP/IP server port you want to use for socket messaging. The client tag is now ready to use from a KAREL program.

The following will indicate how to set the Client and the Karel code to communicate with the FlexiBowl. This script can be called to move the FlexiBowl or to put it in a parallel task, and to regulate the execution through a traffic light.
The code will receive a command to execute, and return a string with the response from the FlexiBowl.

STEP 2:




Host Client C7 configuration to communicate with the FlexiBowl address: 192.168.1.10






STEP 3:

System Variable configuration









STEP 4:

File Karel

Once the client is configured we insert the FLB_PLUGIN.PC file in the controller. To do this, copy the file into a USB stick and connect it to the pendant's USB port.








STEP 5:

Run the commands from the Tp program

Once the client is configured, after importing the Flb_Plugin.pc file, it will be possible to move the FlexiBowl or make diagnostics from the Tp program, the FlexiBowl response will be inserted in the String [10], editable by Karel.



Example of KAREL code:

```
PROGRAM Flb_Plugin
```

```
VAR
```

```
PingAddress:BOOLEAN  
return_string : STRING[128]  
status : INTEGER  
moving:INTEGER  
cmd_type: INTEGER  
cmd_int_val:INTEGER  
cmd_real_val:REAL  
cmd_str_val:STRING[128]
```

```
command_Str:STRING[128]  
file_var : FILE  
tmp_str : STRING[128]  
tmp_str1:STRING[128]  
tmp_str2:STRING[128]  
entry : INTEGER
```

```
ROUTINE Ping  
BEGIN
```

```
    PingAddress=FALSE  
    MSG_DISCO('C7:',status)  
    MSG_CONNECT('C7:',status)  
    IF(status=0) THEN  
        PingAddress=TRUE  
    else  
        PingAddress=FALSE  
    ENDIF  
    MSG_DISCO('C7:',status)
```

```
END Ping
```

```
---////////////////////////////////////  
---////////////////////////////////////SENDCOMMAND////////////////////////////////////  
--////////////////////////////////////
```

```
ROUTINE SendCommand(CommandExecute:STRING):STRING
```

```
BEGIN
```

```
return_string='FAIL';  
command_Str=CommandExecute
```

```
CLR_IO_STAT(file_var)
status = IO_STATUS(file_var)
IF status = 0 THEN
  --Write
  tmp_str=CHR(0)+CHR(7)+ command_Str + CHR(13)
  WRITE file_var (tmp_str)
  IF( IO_STATUS(file_var)<>0) THEN
    return_string='FAIL'
    WRITE ('Status var OUT fail',CR)
    go to end_it
  ENDIF

  --READ
  entry=0
  WHILE entry <1 DO
    BYTES_AHEAD(file_var, entry, status)
  ENDWHILE

  STATUS = IO_STATUS(file_var)
  IF(STATUS<>0)THEN
    return_string='FAIL'
    WRITE ('Status var IN fail',CR)
    go to end_it
  ENDIF
  IF (entry>0) THEN
    READ file_var (tmp_str1::entry)
    tmp_str2=SUB_STR(tmp_str1,2,entry-1)
    return_string=tmp_str2
  ELSE
    return_string='FAIL'
    go to end_it
  ENDIF
ELSE
  WRITE ('Status var fail',CR)
  return_string='FAIL'
  go to end_it
ENDIF

end_it::
RETURN(return_string)
END SendCommand
-----//
```

```

BEGIN
    GET_TPE_PRM(1,cmd_type,cmd_int_val,cmd_real_val,cmd_str_val,S
STATUS)
    IF(STR_LEN(cmd_str_val)>0) THEN
        command_Str=cmd_str_val
    else
        return_string='FAIL'
        go to end_it2

    ENDIF
    --setto i parametri di connessione
    SET_FILE_ATR(file_var, ATR_IA)
    MSG_DISCO('C7:', status)
    MSG_CONNECT('C7:',status)
    IF(status <> 0) THEN
        return_string='FAIL'
        go to end_it2
    ENDIF
    OPEN FILE file_var ('RW','C7:')
    return_string=SendCommand(command_Str)
    IF((INDEX(return_string,'%')<>0)
        AND (INDEX(command_Str,'Q')<>0)) THEN
        -----wait move
        moving=1
        WHILE (moving = 1) DO
            command_Str='RS'
            return_string=SendCommand(command_Str)
            IF(INDEX(return_string,'F')>0) THEN
                moving = 1
            else
                moving = 0
            ENDIF
            DELAY(50)
        ENDWHILE
        return_string='Done'
    else
        return_string=return_string
    ENDIF
end_it2::
    CLOSE FILE file_var
    MSG_DISCO('C7:',status)

    --write the return on string 10
    SET_STR_REG(10,return_string,status)
END Fib_Plugin

```


Lista dei comandi:

Action	Description
MOVE	Moves the feeder the current parameters.
MOVE-FLIP	Moves the feeder and activates Flip simultaneously
MOVE-BLOW-FLIP	Moves the feeder and activates Flip and blow simultaneously
MOVE-BLOW	Moves the feeder and activates Flip simultaneously
SHAKE	Shakes the feeder with the current parameters
LIGHT ON	Light on
LIGHT OFF	Light off
FLIP	Flip
BLOW	Blow
QUICK_EMPTYING	Quick Emptying Option
RESET_ALARM	Reset Alarm and enable the motor

Commands	Description
QX2	Move
QX3	Move-Flip
QX4	Move-Flip-Blow
QX5	Move-Blow
QX6	Shake
QX7	Light on
QX8	Light off
QX9	Blow
QX10	Flip
QX11	Quick Emptying Option
QX12	Reset Alarm

